

Thumper Jockey Sur-Ron

1. Flip the main breaker off before installing the lights.
2. Remove the two battery cover hinge pins by removing the small clip on each pin and remove the cover.



3. Remove the two bolts holding the ignition.



4. Remove the OE headlight by removing the 4 bolts holding the headlight bracket on.



5. Trace the headlight wire to the wire harness shown below and unplug it.



6. Plug the supplied wire harness into the connector the OE headlight was plugged into.



7. Replace the ignition. Make sure the cables are still routed above the key switch and not pinched.



8. Mount the switch by removing the mount bracket that secures the front brake to the handlebars. Replace the mount bracket with the switch using the supplied (longer) bolts.



9. Attach the fork mounts and lights as shown below using the diagram on the last page.



10. Connect the lights to the wire harness and use the large zip tie to secure the connectors to the frame. Use the additional zip ties to secure loose wires.



Thumper Jockey

Model: Sur-Ron

